

Yamayo measuring the world

YAMAYO tape measure correction slide rule

Tension compensation

Ground measurement

Standard tension


For tension compensation

Measured tension

For looseness correction

Measurement length

Looseness correction



For positive tension

inclination correction

Temperature compensation

Measured temperature

Constant correction

Nominal tension

Positive tension

(Intermediate measurement)

